





























Tinten		Artikelbeschreibung	
C13T07114		Tintenpatrone schwarz	Epson Stylus D78/D92/D120/DX4000/DX4050/DX4400/DX5000/DX5050/DX6000/DX6050/DX7000F/DX7400/DX7450/DX8400/DX8450/DX9400F/S20/S21/SX100/SX105/SX110/SX115/SX200/SX205/SX210/SX215/SX400/SX405/SX410/SX415/SX510W/SX515W/SX600FW/SX610FW Epson Stylus Office B40W/BX300F/BX310FN/BX600FW/BX610FW
C13T07154		Multipack	Epson Stylus D78/D92/D120/DX4000/DX4050/DX4400/DX5000/DX5050/DX6000/DX6050/DX7000F/DX7400/DX7450/DX8400/DX8450/DX9400F/S20/S21/SX100/SX105/SX110/SX115/SX200/SX205/SX210/SX215/SX400/SX405/SX410/SX415/SX510W/SX515W/SX600FW/SX610FW Epson Stylus Office B40W/BX300F/BX310FN/BX600FW/BX610FW
C13T07124		Tintenpatrone cyan	Epson Stylus D78/D92/D120/DX4000/DX4050/DX4400/DX5000/DX5050/DX6000/DX6050/DX7000F/DX7400/DX7450/DX8400/DX8450/DX9400F/S20/S21/SX100/SX105/SX110/SX115/SX200/SX205/SX210/SX215/SX400/SX405/SX410/SX415/SX510W/SX515W/SX600FW/SX610FW Epson Stylus Office B40W/BX300F/BX310FN/BX600FW/BX610FW
C13T08914		Tintenpatrone schwarz	Epson Stylus S20/S21/SX100/SX105/SX110/SX115/SX200/SX205/SX210/SX215/SX400/SX405/SX410/SX415 Epson Stylus Office BX300F/SX218
C13T12814		Tintenpatrone schwarz	Epson Stylus S22, SX125, SX420/W/425W/BX305F/BX305FW/
C13T06114		Tintenpatrone schwarz	Epson Stylus D68 Series/D88 Series/DX3800 Series/DX4200 Series/DX4800 Series
C13T07134		Tintenpatrone magenta	Epson Stylus D78/D92/D120/DX4000/DX4050/DX4400/DX5000/DX5050/DX6000/DX6050/DX7000F/DX7400/DX7450/DX8400/DX8450/DX9400F/S20/S21/SX100/SX105/SX110/SX115/SX200/SX205/SX210/SX215/SX400/SX405/SX410/SX415/SX510W/SX515W/SX600FW/SX610FW Epson Stylus Office B40W/BX300F/BX310FN/BX600FW/BX610FW
C13T07144		Tintenpatrone yellow	Epson Stylus D78/D92/D120/DX4000/DX4050/DX4400/DX5000/DX5050/DX6000/DX6050/DX7000F/DX7400/DX7450/DX8400/DX8450/DX9400F/S20/S21/SX100/SX105/SX110/SX115/SX200/SX205/SX210/SX215/SX400/SX405/SX410/SX415/SX510W/SX515W/SX600FW/SX610FW Epson Stylus Office B40W/BX300F/BX310FN/BX600FW/BX610FW
C13T12854		Multipack	Epson Stylus S22, SX125, SX420/W/425W/BX305F/BX305FW/
C13T06154		Multipack	Epson Stylus D68 Series/D88 Series/DX3800 Series/DX4200 Series/DX4800 Series
C13T12914		Tintenpatrone schwarz	Epson Stylus SX420W/SX425W/SX525WD/SX620FW/BX305F/BX305FW/BX320FW/BX525WD/BX625FWD/BX925FWD/B42WD
C13T08964		Tripack	Epson Stylus S20/S21/SX100/SX105/SX110/SX115/SX200/SX205/SX210/SX215/SX400/SX405/SX410/SX415 Epson Stylus Office BX300F/S218
C13T08074		Multipack	Epson Stylus Photo R265/R285/R360/RX560/RX585/RX685/P50/PX700W/PX800FW/PX810FW/PX710W/PX650/PX660/PX720WD/PX820FWD/PX660
C13T08014		Tintenpatrone schwarz	Epson Stylus Photo R265/R285/R360/RX560/RX585/RX685/P50/PX700W/PX800FW/PX810FW/PX710W/PX650/PX660/PX720WD/PX820FWD/PX660
C13T12954		Multipack	Epson Stylus SX420W/SX425W/SX525WD/SX620FW/BX305F/BX305FW/BX320FW/BX525WD/BX625FWD/BX925FWD/B42WD
C13T08924		Tintenpatrone cyan	Epson Stylus S20/S21/SX100/SX105/SX110/SX115/SX200/SX205/SX210/SX215/SX400/SX405/SX410/SX415 Epson Stylus Office BX300F/SX218

Rangliste Tinte April 2011

C13T12824		Tintenpatrone cyan	Epson Stylus S22, SX125,SX420/W/425W/BX305F/BX305FW/
C13T12834		Tintenpatrone magenta	Epson Stylus S22, SX125,SX420/W/425W/BX305F/BX305FW/
C13T12844		Tintenpatrone yellow	Epson Stylus S22, SX125,SX420/W/425W/BX305F/BX305FW/
C13T06124		Tintenpatrone cyan	Epson Stylus D68 Series/D88 Series/DX3800 Series/DX4200 Series/DX4800 Series
C13T08934		Tintenpatrone magenta	Epson Stylus S20/S21/SX100/SX105/SX110/SX115/SX200/SX205/SX210/SX215/SX400/SX405/SX410/SX415 Epson Stylus Office BX300F/SX218
C13T08944		Tintenpatrone yellow	Epson Stylus S20/S21/SX100/SX105/SX110/SX115/SX200/SX205/SX210/SX215/SX400/SX405/SX410/SX415 Epson Stylus Office BX300F/SX218
C13T13014		Tintenpatrone schwarz	Epson Stylus SX620FW, SX525WD, BX525WD, BX625FWD, BX925FWD
C13T07914		Tintenpatrone schwarz	Epson Stylus PhotoP50/PX700W/PX800FW/PX810FW/PX710W/PX650/PX660/PX720WD/PX820FWD/PX660
C13T06134		Tintenpatrone magenta	Epson Stylus D68 Series/D88 Series/DX3800 Series/DX4200 Series/DX4800 Series
C13T05564		Multipack	Epson R240, R245, RX420 RX425,RX520
C13T10014		Tintenpatrone, schwarz	Epson Stylus Office B1100, SX600FW,B40W, BX600FW, BX310FN, SX510W, SX515W, SX610FW, BX610FW
C13T08054		Tintenpatrone light cyan	Epson Stylus Photo R265/R285/R360/RX560/RX585/RX685/P50/PX700W/PX800FW/PX810FW/PX710W/PX650/PX660 0/PX720WD/PX820FWD/PX660
C13T08064		Tintenpatrone, light magenta	Epson Stylus Photo R265/R285/R360/RX560/RX585/RX685/P50/PX700W/PX800FW/PX810FW/PX710W/PX650/PX660 0/PX720WD/PX820FWD/PX660
C13T06144		Tintenpatrone yellow	Epson Stylus D68 Series/D88 Series/DX3800 Series/DX4200 Series/DX4800 Series